





10000

--	--	--	--	--	--	--	--

□□□□□□□□□□□□□□20□□□□□□□□

20□□□□□□□□

20

Esteban Paris Leoban Target TJ Max

XXXXXXXXXXXXXXXXXXXXFDA XXXXXXXXXXXXXXX

[illegible]

□ □ □ □ □



Cupwind OEM/ODM



TEST REPORT



(8521)087-0435
Page 3 of 4

Call 65 Pro ASTM

ATTN: EMMA ZOU
Email: zouemma@cupwind.com

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)087-0435

DATE OF TEST: APR 11, 2024
DATE OUT: /
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING

PASS ☒
FAIL ☐
DATA ☐

TESTING FOR CA, Pb, LEAD & CADMIUM ON NON-FOOD BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR	PLT No.:	7
Buyer:	SPDY	Shop:	7
Country of Origin:	CHINA	Country of Destination:	USA
Color:	IRIDESCENT	SKU Number:	ITEM# 8090
Brand name:	CUPWIND B		
Re-test:	Yes: ☐ No: ☒	Change Vendor:	Yes: ☒ No: ☐
Previous Report No.:	7		

EXECUTIVE SUMMARY:

Test Content		Result Rating
CA, Pb, Lead & Cadmium on non-food/beverage glassware-exterior		Meet Pass
Chemical resistance of annealing	ASTM F2175-20 Sec. 4.2 (NA6)	M
	With a tungsten carbide scribe, scratch twice around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test.	PASS
Thermal shock	ASTM F2175-20 Sec. 4.2 (NA6) / ASTM C148	M
	Modification: expanded scope to all other glass products in addition to candle containers. Shall not crack or break after tested per below: - prepare a cold-water bath at 21 ± 1.1°C (70 ± 2°F); - prepare a hot bath at 71 ± 1.1°C (160 ± 2°F); - immerse the sample completely in the hot water bath and allow to soak for 5 min ± 15 s; - transfer the sample to the cold bath and immerse for at least 30 s; - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion. - the time of transfer from the hot bath to the cold bath shall be 15 ± 1 s. Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.	PASS

REMARK:

1. No enclosed protocol for test results in this report.

□□□□□□□□

