

New Mould Geo Cut Reed Diffusor Flaschenglas



Dieses zylinderförmige Diffusorflaschenglas enthält 6 Unzen Duftöl. Das Geo-Cut-Muster ist ziemlich weit verbreitet in [Porzellanfabrik für Diffusorflaschen](#)

Das klare Glas ist in der Lage, verschiedene Pantone-Farben zu sprühen, wodurch es gut zu verschiedenen Designs von Kerzenglas und Duftdüften passt. Es ist perfekt für Wohnkultur, Aromatherapie, Spa, Meditation, Badezimmer.





Diese Flasche mit Geo-Cut-Design ist ein beliebtes Design, es gibt genau das gleiche Muster, das auf ein Kerzenglas aus Glas abgestimmt ist, das bei Indie-Marken sehr beliebt ist. Es ist ein sehr gut passendes Wohnkulturprodukt für Kunden. Die leere Glasdiffusorflasche ist auch eine gute Vase für Blumen, einfach und klassisch.



Cupwind ist einer der professionellsten [Hersteller von Reed-Diffusorflaschen aus China](#). Wir haben unsere eigene Dekorationswerkstatt, um die Qualität der Reed-Diffusorflasche vor dem Versand im Auge zu behalten.

Das MOQ dieser Diffusorflasche mit rundem Körper beträgt 30.000 Stück.









Cupwind bietet auch weiteres Zubehör an, das sich auf die Reed-Diffusorflasche bezieht, wie Reed, Stöpsel, Geschenkbox, Stopfen usw.

Wir haben seit Jahren 6 stabile Kooperationspartner. Die Qualität passt hervorragend zu unseren Kerzenhaltern.



Accessories That Related

With requests of our customers, Cupwind also offers accessories such as gift box for scented candles, wick tool set like wick trimmer, cutter, snuffer, lids in wood and metal like stainless steel and zinc alloy.



Zinc Alloy Lid

Wick Trimmer Cutter



Wooden Lid

Tin metal lid



Glass Lid

Stopper



Neck

Reed



Gift Box

Gift Box



Wir bieten auch Geschenkboxen OEM und ODM für Reed-Diffusorflaschen an. Wenn keine Geschenkbox erforderlich ist, ist es üblich, jede Glasdiffusorflasche mit einem Opp-Beutel zu umwickeln, um Staub fernzuhalten. Wellpappenkartons mit Querbrettern. Holzpaletten sind beim Transport immer effizient, und wir fügen ein Baumwollnetz an der Tür hinzu, um beim Öffnen der Containertür vor dem Herunterfallen zu schützen.



Alle unsere Glasbestellungen werden von Dritten getestet. Normalerweise gehen wir mit Cali 65 Pro-Tests, ASTM-Tests (Annealing and Thermal Shock), Blei- und Cadmium-Tests.



TEST REPORT



(8521)097-0435
Page 3 of 4

SHENZHEN JIERUMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENGANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

| OVERALL RATING | |
|----------------|-------|
| PASS | X |
| FAIL | _____ |
| DATA | _____ |

TESTING FOR
CA 65 LEAD & CADMIUM ON NON-FOOD /
BEVERAGE GLASSWARE-EXTERIOR

| | | | |
|----------------------|-------------------------------|---|--|
| Sample Description: | IRIDESCENT COATING CANDLE JAR | | |
| Manufacturer: | CUPWIND COOPERATED FACILITY | P.O. No.: | / |
| Buyer: | IPSY | Style: | / |
| Country of Origin: | CHINA | Country of Destination: | USA |
| Color: | IRIDESCENT | SKU Number: | ITEM#: 8090 |
| Brand name: | CUPWIND ® | | |
| Re-test: | Yes: <input type="checkbox"/> | No: <input checked="" type="checkbox"/> | Charge Vendor: Yes: <input checked="" type="checkbox"/> No: <input type="checkbox"/> |
| Previous Report No.: | / | | |

EXECUTIVE SUMMARY:

| Test content | Result/Rating |
|--|---------------|
| CA 65 Lead & Cadmium on non-food/beverage glassware-exterior | Meet/Pass |

| Effectiveness of annealing | ASTM F2179-20 Sec. 4.2 (Mod) | With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test. | M | PASS |
|----------------------------|--|---|---|------|
| | | Modification: expanded scope to all other glass products in addition to candle containers. | | |
| Thermal shock | ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149 | Shall not crack or break after tested per below - prepare a cold-water bath at 21±1.1°C (70 ± 2°F), - prepare a hot bath at 71 ± 1.1°C (160 ± 2°F) - immerse the sample completely in the hot water bath and allow to soak for 5 min ± 10 s. - transfer the sample to the cold bath, and immerse for at least 30 s. - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion - the time of transfer from the hot bath to the cold bath shall be 15 ± 1 s Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers. | M | PASS |

REMARK:

- No enclosed protocol for test results in this report.