

Großhandel schillernde Kerzengläser blau 8oz



Unsere Stärke:

10000 Quadratmeter Dekorationswerkstatt.

20 verschiedene Dekorationsmaschinen.

20 Jahre Erfahrung im Dekorationsbereich.

20 stabile Glasfabriken unterstützen.

Weltweit bekannte Marken wie Armani Zara etc.

Cupwind ist [Großhandel mit schillernden Kerzengläsern in China](#) seit mehr als 10 Jahren.



Irisierende Beschichtung auf der Außenseite, blaue Sprays auf der Innenseite

stabile Beschichtung, die den M616-Kreuzschraffurtest bestehen kann

MOQ 2000 Stück auf der schillernden Beschichtung

Luxus-Look, der der neue Trend auf dem Markt ist



Cupwind bietet auch Zubehör für Kerzenhalter an, wie z [Kerzen-Werkzeugset](#) einschließlich
Dochtschneider, Dochtlöscher, [Kerzentablett](#), Deckel für Kerzengläser wie Edelstahldeckel,
Holzdeckel, Bambusdeckel mit Dichtung.



Wick Trimmer Cutter



Zinc Alloy Lid



Wooden Lid



Neck



Stopper



Reed



Gift Box.



Gift Box

All die [Kerzenhalter](#) Produkte, die wir versenden, werden von Dritten getestet, die Tests, die wir normalerweise durchführen, wie Glühen und Thermoschock, Blei und Cadmium.



TEST REPORT

SHENZHEN JIERUIMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENGGAO, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING

PASS	X
FAIL	
DATA	

TESTING FOR CA 65 LEAD & CADMIUM ON NON-FOOD/ BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR
Manufacturer:	CUPWIND COOPERATED
Facility:	IPSY
Buyer:	Style: /
Country of Origin:	CHINA
Country of Destination:	USA
Color:	IRIDESCENT
SKU Number:	ITEM#: 8090
Brand name:	CUPWIND®
Re-test:	Yes: ☐ No: ☒
Charge Vendor:	Yes: ☒ No: ☐
Previous Report No.:	/



(8521)097-0435
Page 3 of 4

EXECUTIVE SUMMARY:

Test content		Results Rating	
CA 65 Lead & Cadmium on non-food beverage glassware-exterior		Meets/Pass	
Effectiveness of annealing	ASTM F2175-20 Sec. 4.2 (Mod)	M	PASS
With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test. Modification: expanded scope to all other glass products in addition to candle containers.			
Thermal shock	ASTM F2175-20 Sec. 4.2 (Mod) / ASTM C149	M	PASS
Shall not crack or break after tested per below: - prepare a cold-water bath at 21±1.1°C (70 ± 2°F). - prepare a hot bath at 71 ± 1.1°C (160 ± 2°F). - immerse the sample completely in the hot water bath and allow to soak for 5 min ± 10 s. - transfer the sample to the cold bath, and immerse for at least 30 s. - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion. - the time of transfer from the hot bath to the cold bath shall be 15 ± 1 s. Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.			

REMARK:

- No enclosed protocol for test results in this report.

Cupwind weiß, wie man jedes Produkt schützt, wir wickeln jedes Glas in einen Opp-Beutel, um Staub zu vermeiden, jedes Kerzenglas ist durch Eierteiler getrennt, damit es nicht aneinander reibt, Holzpaletten sind beim Transport am Ende vorzuziehen Fügen Sie ein

Baumwollnetz an der Containertür hinzu, um die Kartons vor dem Herunterfallen zu schützen.

