

Vaso per candele in oro rosa metallizzato 11oz

Le tecniche di metallizzazione dell'oro rosa sono ampiamente utilizzate su barattoli di candele, lampade, metalli, anche l'iPhone lo sta usando sul telefono. Il barattolo di candela in oro rosa è un arredamento di lusso per la casa e un barattolo di candela profumato.



Cupwind è il leader [fornitore di barattoli di candele in oro rosa in Cina](#). Abbiamo 5 macchine galvaniche di metallizzazione nella nostra officina. Ogni giorno possiamo produrre 30.000 vasetti di candele in oro rosa.



Cupwind è il principale produttore di vasi per candele in oro rosa in Cina. Abbiamo il nostro laboratorio in 6000m² , e abbiamo 70 persone per fare la metallizzazione galvanica.



Cupwind offre design di scatole regalo e vendita all'ingrosso. Se non è necessaria una confezione regalo, il modo comune che utilizziamo è avvolgere ogni portacandele in vetro con un sacchetto di opp per tenerlo lontano dalla polvere, quindi ogni scatola di cartone contiene 48 pezzi di vetro per candele separati da un divisore per uova. I pallet di legno sono sempre efficienti durante il trasporto e aggiungeremo una rete di cotone nel posto della porta per proteggerla dalla caduta quando si apre la porta del contenitore.



TEST REPORT



(8521)097-0435
Page 3 of 4

SHENZHEN JIERUIMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENGANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING	
PASS	☒
FAIL	☐
DATA	☐

TESTING FOR
CA 65 LEAD & CADMIUM ON NON-FOOD /
BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR		
Manufacturer:	CUPWIND COOPERATED	P.O. No.:	/
Buyer:	IPSY	Style:	/
Country of Origin:	CHINA	Country of Destination:	USA
Color:	IRIDESCENT	SKU Number:	ITEM# 8090
Brand name:	CUPWIND®		
Re-test:	Yes: ☐ No: ☒	Charge Vendor:	Yes: ☒ No: ☐
Previous Report No.:	/		

EXECUTIVE SUMMARY:

Test content		Result/Rating
CA 65 Lead & Cadmium on non-food/beverage glassware-exterior		Meet/Pass
Effectiveness of annealing	ASTM F2179-20 Sec. 4.2 (Mod)	M PASS
	With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test. Modification: expanded scope to all other glass products in addition to candle containers.	
Thermal shock	ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149	M PASS
	Shall not crack or break after tested per below - prepare a cold-water bath at $21 \pm 1.1^{\circ}\text{C}$ ($70 \pm 2^{\circ}\text{F}$). - prepare a hot bath at $71 \pm 1.1^{\circ}\text{C}$ ($160 \pm 2^{\circ}\text{F}$). - immerse the sample completely in the hot water bath and allow to soak for $5 \text{ min} \pm 10 \text{ s}$. - transfer the sample to the cold bath, and immerse for at least 30 s. - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion - the time of transfer from the hot bath to the cold bath shall be $15 \pm 1 \text{ s}$ Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.	

REMARK:

1. No enclosed protocol for test results in this report.

Tutti i portacandele in vetro che abbiamo spedito sono testati da una terza parte. I test che facciamo sempre come i test di Ricottura e Shock Termico, i test Cali 65 Pro, i test Piombo e Cadmio.