

## **Butelka akwarelowa o pojemności 7 uncji z dyfuzorem artystycznym**



Szkło dyfuzora może rozpylać różne kolory pantone, dzięki czemu dobrze komponuje się z różnymi wzorami szkła do świece i zapachami. Jest idealny do wystroju domu, aromaterapii, spa, medytacji, łazienki.



Ten dyfuzor z ręcznie wykonanym akwarelowym wzorem, jest do niego pasujący wzór świec. Jest to bardzo dobrze dopasowany produkt do wystroju domu dla klientów. Pusta szklana butelka z dyfuzorem to również dobry wazon na kwiaty, prosty i klasyczny.



Cupwind jest jednym z najbardziej profesjonalnych [Chiny Producent butelek z dyfuzorem o pojemności 7 uncji](#). Posiadamy własny warsztat dekoracyjny, który monitoruje jakość butelki z dyfuzorem trzcinowym przed jej wysyłką.











Cupwind oferuje również inne akcesoria związane z butelką z dyfuzorem trzcinowym, takie jak trzcina, zatyczka, pudełko upominkowe, korek itp.

Od lat mamy 6 stabilnych partnerów kooperacyjnych. Jakość doskonale pasuje do naszych świeczników.



## Accessories That Related

With requests of our customers, Cupwind also offers accessories such as gift box for scented candles, wick tool set like wick trimmer, cutter, snuffer, lids in wood and metal like stainless steel and zinc alloy.



Zinc Alloy Lid

Wick Trimmer Cutter



Wooden Lid

Tin metal lid



Glass Lid

Stopper



Neck

Reed



Gift Box

Gift Box



Oferujemy również pudełka upominkowe OEM i ODM na butelki z dyfuzorem trzcinowym. Jeśli pudełko upominkowe nie jest konieczne, powszechnym sposobem, którego używamy, jest owinięcie każdej szklanej butelki z dyfuzorem torbą przeciwpylową, aby chronić ją przed kurzem, kartony z tektury falistej z przekładkami poprzecznymi. Paleta drewniana zawsze sprawdza się w transporcie, oraz dodamy bawełnianą siatkę w miejscu drzwi, aby zabezpieczyć przed upadkiem podczas otwierania drzwi kontenera.



Wszystkie nasze zamówienia na szkło są testowane przez stronę trzecią. Zwykle korzystamy z testów Cali 65 Pro, testów ASTM (wyżarzania i szoku termicznego), testów ołowiu i kadmu.



## TEST REPORT



(8521)097-0435  
Page 3 of 4

SHENZHEN JIERUMA TRADING CO., LTD  
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,  
HENGANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN  
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU  
CC: emma@cupwind.com

DATE IN: APR 07, 2021  
MOD. LOG IN: /  
DATE OUT: APR 13, 2021  
REVISED DATE: /  
WORKING DAYS: 5  
PAGE: 2 OF 4

### OVERALL RATING

PASS ☒  
FAIL ☐  
DATA ☐

TESTING FOR  
CA 65 LEAD & CADMIUM ON NON-FOOD /  
BEVERAGE GLASSWARE-EXTERIOR

|                      |                                                                       |                         |                                                                       |
|----------------------|-----------------------------------------------------------------------|-------------------------|-----------------------------------------------------------------------|
| Sample Description:  | IRIDESCENT COATING CANDLE JAR                                         |                         |                                                                       |
| Manufacturer:        | CUPWIND COOPERATED FACILITY                                           | P.O. No.:               | /                                                                     |
| Buyer:               | IPSY                                                                  | Style:                  | /                                                                     |
| Country of Origin:   | CHINA                                                                 | Country of Destination: | USA                                                                   |
| Color:               | IRIDESCENT                                                            | SKU Number:             | ITEMF: 8090                                                           |
| Brand name:          | CUPWIND®                                                              |                         |                                                                       |
| Re-test:             | Yes: <input type="checkbox"/> No: <input checked="" type="checkbox"/> | Charge Vendor:          | Yes: <input checked="" type="checkbox"/> No: <input type="checkbox"/> |
| Previous Report No.: | /                                                                     |                         |                                                                       |

### EXECUTIVE SUMMARY:

| Test content                                                 |                                          | Result/Rating                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |        |
|--------------------------------------------------------------|------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|
| CA 65 Lead & Cadmium on non-food/beverage glassware-exterior |                                          | Meet/Pass                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |        |
| Effectiveness of annealing                                   | ASTM F2179-20 Sec. 4.2 (Mod)             | With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test.<br><br>Modification: expanded scope to all other glass products in addition to candle containers.                                                                                                                                                                                                                                                                                          | M PASS |
| Thermal shock                                                | ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149 | Shall not crack or break after tested per below<br>- prepare a cold-water bath at $21 \pm 1.1^\circ\text{C}$ ( $70 \pm 2^\circ\text{F}$ ).<br>- prepare a hot bath at $71 \pm 1.1^\circ\text{C}$ ( $160 \pm 2^\circ\text{F}$ )<br>- Immerse the sample completely in the hot water bath and allow to soak for $5 \text{ min} \pm 10 \text{ s}$ .<br>- transfer the sample to the cold bath, and immerse for at least 30 s.<br>- remove the sample from the cold bath and examine the sample for any cracking.<br>Note:<br>- the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion<br>- the time of transfer from the hot bath to the cold bath shall be $15 \pm 1 \text{ s}$<br>Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers. | M PASS |

### REMARK:

1. No enclosed protocol for test results in this report.