

Frasco de vidro difusor de spray de luxo personalizado de 8 onças



O design redondo comum faz com que combine bem com diferentes designs de vidro de vela. É perfeito para decoração de casa, aromaterapia, spa, meditação, banheiro.



Esta garrafa com design de listras especial é um item popular entre muitas marcas diferentes. O frasco difusor de vidro vazio também é um bom vaso para flores, simples e clássico.

Te traz alegria e amor.



Cupwind é um dos mais profissionais [China fabricante de garrafa de difusor de vidro personalizado](#). Temos nossa própria oficina de decoração para ficar de olho na qualidade da garrafa difusora de junco antes de ser enviada.

O MOQ desta garrafa difusora em forma de corpo redondo é de 30.000 peças.









A Cupwind também oferece outros acessórios relacionados ao frasco difusor de palheta, como palheta, plugue, caixa de presente, rolha etc.

Temos 6 parceiros cooperativos estáveis há anos. A qualidade é uma ótima combinação com nossos castiçais.



Accessories That Related

With requests of our customers, Cupwind also offers accessories such as gift box for scented candles, wick tool set like wick trimmer, cutter, snuffer, lids in wood and metal like stainless steel and zinc alloy.

 <p>Zinc Alloy Lid</p>	 <p>Wick Trimmer Cutter</p>
 <p>Wooden Lid</p>	 <p>Tin metal lid</p>
 <p>Glass Lid</p>	 <p>Stopper</p>
 <p>Neck</p>	 <p>Reed</p>
 <p>Gift Box</p>	 <p>Gift Box</p>

Também oferecemos caixa de presente OEM e ODM para garrafas de difusor de junco.

Se a caixa de presente não for necessária, a maneira comum que estamos usando é embrulhar cada garrafa difusora de vidro por um saco opp para evitar poeira,

caixas de papelão ondulado com divisórias cruzadas. Palete de madeira é sempre eficiente durante o transporte,

e adicionaremos uma rede de algodão no local da porta para evitar quedas ao abrir a porta do contêiner.



Todos os nossos pedidos de vidro são testados por terceiros. Normalmente vamos com testes Cali 65 Pro, testes ASTM (Annealing and Thermal Shock), testes de chumbo e cádmio.



TEST REPORT



(8521)097-0435
Page 3 of 4

SHENZHEN JIERUMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENG GANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING	
PASS	X
FAIL	_____
DATA	_____

TESTING FOR
CA 65 LEAD & CADMIUM ON NON-FOOD/
BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR		
Manufacturer:	CUPWIND COOPERATED FACILITY	P.O. No.:	/
Buyer:	IPSY	Style:	/
Country of Origin:	CHINA	Country of Destination:	USA
Color:	IRIDESCENT	SKU Number:	ITEM#: 8090
Brand name:	CUPWIND ®		
Re-test:	Yes: <input type="checkbox"/>	No: <input checked="" type="checkbox"/>	Charge Vendor: Yes: <input checked="" type="checkbox"/> No: <input type="checkbox"/>
Previous Report No.:	/		

EXECUTIVE SUMMARY:

Test content	Result/Rating	Meet/Pass	
CA 65 Lead & Cadmium on non-food/beverage glassware-exterior			
Effectiveness of annealing	ASTM F2179-20 Sec. 4.2 (Mod)	M	PASS
Thermal shock	ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149	M	PASS

With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test.

Modification: expanded scope to all other glass products in addition to candle containers.

Shall not crack or break after tested per below

- prepare a cold-water bath at 21 ± 1.1°C (70 ± 2°F).
- prepare a hot bath at 71 ± 1.1°C (160 ± 2°F)
- Immerse the sample completely in the hot water bath and allow to soak for 5 min ± 10 s.
- transfer the sample to the cold bath, and immerse for at least 30 s.
- remove the sample from the cold bath and examine the sample for any cracking.

Note:

- the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion
- the time of transfer from the hot bath to the cold bath shall be 15 ± 1 s

Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.

REMARK:

- No enclosed protocol for test results in this report.