

Недавно разработанные пустые стильные диффузоры из бутылочного стекла



Прозрачное стекло способно распылять различные цвета пантона, что делает его хорошо сочетающимся с различными дизайнами стекла для свечей и ароматами. Он идеально подходит для домашнего декора, ароматерапии, спа, медитации, ванной комнаты.



Эта бутылка с полосатым дизайном является популярным дизайном, для нее есть подходящий дизайн баночки для свечи. Это очень хороший продукт для домашнего декора для клиентов. Пустая стеклянная бутылка с диффузором также является хорошей вазой для цветов, простой и классической.



Сирwind — один из самых профессиональных [Китайский производитель стеклянной тары с диффузорами](#). У нас есть собственная мастерская по декорированию, чтобы следить за качеством бутылок с тростниковыми диффузорами перед их отправкой.

Минимальный объем заказа этой бутылки с диффузором специальной формы составляет 30 000 шт.









Сирwind также предлагает другие аксессуары, связанные с бутылкой с тростниковым диффузором, такие как тростник, заглушка, подарочная коробка, пробка и т. д.

У нас есть 6 стабильных партнеров по сотрудничеству в течение многих лет. Качество отлично сочетается с нашими подсвечниками.



Accessories That Related

With requests of our customers, Cupwind also offers accessories such as gift box for scented candles, wick tool set like wick trimmer, cutter, snuffer, lids in wood and metal like stainless steel and zinc alloy.



Zinc Alloy Lid

Wick Trimmer Cutter



Wooden Lid

Tin metal lid



Glass Lid

Stopper



Neck

Reed



Gift Box

Gift Box



Мы также предлагаем подарочные коробки OEM и ODM для бутылок с тростниковыми диффузорами. Если подарочная коробка не нужна, обычно мы используем обертку каждой стеклянной бутылки с диффузором в полипропиленовый пакет для защиты от пыли. гофрированные коробки с поперечными разделителями. Деревянный поддон всегда эффективен при транспортировке, и мы добавим хлопчатобумажную сетку в место двери, чтобы защитить от падения при открытии двери контейнера.



Все наши стеклянные заказы проверяются третьей стороной. Обычно мы используем тесты Cali 65 Pro, тесты ASTM (отжиг и тепловой удар), тесты на свинец и кадмий.



TEST REPORT



(8521)097-0435
Page 3 of 4

SHENZHEN JIERUMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENGANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING	
PASS	X
FAIL	_____
DATA	_____

TESTING FOR
CA 65 LEAD & CADMIUM ON NON-FOOD/
BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR		
Manufacturer:	CUPWIND COOPERATED FACILITY	P.O. No.:	/
Buyer:	IPSY	Style:	/
Country of Origin:	CHINA	Country of Destination:	USA
Color:	IRIDESCENT	SKU Number:	ITEM#: 8090
Brand name:	CUPWIND ®		
Re-test:	Yes: <input type="checkbox"/>	No: <input checked="" type="checkbox"/>	Charge Vendor: Yes: <input checked="" type="checkbox"/> No: <input type="checkbox"/>
Previous Report No.:	/		

EXECUTIVE SUMMARY:

Test content	Result/Rating
CA 65 Lead & Cadmium on non-food/beverage glassware-exterior	Meet/Pass

Effectiveness of annealing	ASTM F2179-20 Sec. 4.2 (Mod)	With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test.	M	PASS
		Modification: expanded scope to all other glass products in addition to candle containers.		
Thermal shock	ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149	Shall not crack or break after tested per below - prepare a cold-water bath at 21±1.1°C (70 ± 2°F), - prepare a hot bath at 71 ± 1.1°C (160 ± 2°F) - immerse the sample completely in the hot water bath and allow to soak for 5 min ± 10 s. - transfer the sample to the cold bath, and immerse for at least 30 s. - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion - the time of transfer from the hot bath to the cold bath shall be 15 ± 1 s Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.	M	PASS

REMARK:

- No enclosed protocol for test results in this report.