

Бутылка-спрей-диффузор премиум-класса ручной работы для украшения комнаты



Стекло диффузора способно распылять различные цвета по шкале Pantone, что позволяет ему хорошо сочетаться со свечами разного дизайна и ароматами. Он идеально подходит для домашнего декора, ароматерапии, спа, медитации, ванной комнаты.



Этот диффузор с акварельным дизайном ручной работы имеет соответствующий дизайн свечей. Это очень хороший предмет домашнего декора для покупателей. Пустая стеклянная бутылка-диффузор также является хорошей вазой для цветов, простой и классической.



Cupwind — один из самых профессиональных [Китайский производитель бутылок с распылителем для помещений](#). У нас есть собственная мастерская по декорированию, чтобы следить за качеством бутылки тростникового диффузора перед ее отправкой.







Cupwind также предлагает другие аксессуары, относящиеся к бутылке с тростниковым диффузором, такие как тростник, заглушка, подарочная коробка, пробка и т. д.

У нас есть 6 стабильных партнеров по сотрудничеству на протяжении многих лет. Качество отлично сочетается с нашими подсвечниками.



Accessories That Related

With requests of our customers, Cupwind also offers accessories such as gift box for scented candles, wick tool set like wick trimmer, cutter, snuffer, lids in wood and metal like stainless steel and zinc alloy.



Zinc Alloy Lid

Wick Trimmer Cutter



Wooden Lid

Tin metal lid



Glass Lid

Stopper



Neck

Reed



Gift Box

Gift Box



Мы также предлагаем подарочные коробки OEM и ODM для бутылок с тростниковым диффузором. Если подарочная коробка не нужна, мы обычно используем способ обернуть каждую стеклянную бутылку-диффузор полиэтиленовым пакетом, чтобы защитить ее от пыли, гофрокартоны с поперечными разделителями. Деревянный поддон всегда эффективен при транспортировке, И мы добавим хлопчатобумажную сетку на место двери, чтобы защитить ее от падения при открытии двери контейнера.



Все наши заказы на стекло проверяются третьей стороной. Обычно мы используем тесты Cali 65 Pro, тесты ASTM (отжиг и термический удар), тесты на свинец и кадмий.



TEST REPORT



(8521)097-0435
Page 3 of 4

SHENZHEN JIERUMA TRADING CO., LTD
NO.415 RUNLIAN BUILDING, SHENZHU ROAD,
HENGANG, 518115, SHENZHEN, CHINA

LAB LOCATION: SHENZHEN
LAB NUMBER: (8521)097-0435

ATTN: EMMA ZOU
CC: emma@cupwind.com

DATE IN: APR 07, 2021
MOD. LOG IN: /
DATE OUT: APR 13, 2021
REVISED DATE: /
WORKING DAYS: 5
PAGE: 2 OF 4

OVERALL RATING

PASS ☒
FAIL ☐
DATA ☐

TESTING FOR
CA 65 LEAD & CADMIUM ON NON-FOOD /
BEVERAGE GLASSWARE-EXTERIOR

Sample Description:	IRIDESCENT COATING CANDLE JAR		
Manufacturer:	CUPWIND COOPERATED FACILITY	P.O. No.:	/
Buyer:	IPSY	Style:	/
Country of Origin:	CHINA	Country of Destination:	USA
Color:	IRIDESCENT	SKU Number:	ITEMF: 8090
Brand name:	CUPWIND 6		
Re-test:	Yes: ☐ No: ☒	Charge Vendor:	Yes: ☒ No: ☐
Previous Report No.:	/		

EXECUTIVE SUMMARY:

Test content		Result/Rating
CA 65 Lead & Cadmium on non-food/beverage glassware-exterior		Meet/Pass
Effectiveness of annealing	ASTM F2179-20 Sec. 4.2 (Mod) With a tungsten carbide scribe, scratch once around the inside knuckle of the article. Then scratch an "X" across the entire inside bottom surface of the article. All scratches are to be made using sufficient pressure to just penetrate the surface of the glass. Fill each article with water at the same room temperature as the glass. Wait 15 minutes, then empty the water and examine each piece for fractures. Shall show no fractures. Report the number of fractures, if any, for each test. Modification: expanded scope to all other glass products in addition to candle containers.	M PASS
Thermal shock	ASTM F2179-20 Sec. 4.2 (Mod) / ASTM C149 Shall not crack or break after tested per below - prepare a cold-water bath at $21 \pm 1.1^{\circ}\text{C}$ ($70 \pm 2^{\circ}\text{F}$). - prepare a hot bath at $71 \pm 1.1^{\circ}\text{C}$ ($160 \pm 2^{\circ}\text{F}$) - immerse the sample completely in the hot water bath and allow to soak for $5 \text{ min} \pm 10 \text{ s}$. - transfer the sample to the cold bath, and immerse for at least 30 s. - remove the sample from the cold bath and examine the sample for any cracking. Note: - the hot water that collects within the container during the first immersion shall be retained in the container through the second immersion - the time of transfer from the hot bath to the cold bath shall be $15 \pm 1 \text{ s}$ Modification: sampling procedure not followed and expanded scope to all other glass products in addition to candle containers.	M PASS

REMARK:

- No enclosed protocol for test results in this report.